

A13

Aprilia RS 125 2017-

Fitting kit left side:

ID	Description	Cat.N	Qty
1	Steel box M10	X1	1
2	Bolt M10x40	854	1
3	Bolt M10x20	819	1
4	Bolt M10x110	879	1
5	Bar bracket	698	1

Fitting kit right side:

ID	Description	Cat.N	Qty
1	Steel box M10	X1	1
2	Bolt M10x40	854	1
3	Nut M10	810	1
4	Washer	804	1
5	Bar bracket	699	1



Instruction to assembly:

1. Take off left and right fairing.
2. Dismantle original bolt M10 in front of engine.
3. Dismantle original bolt from frame on the left side (red market on picture 1).
4. Put bracket and fixed it by bolt ID.3 and insert through bolt ID.4
5. On the right side dismantle orig.bolt.
6. Put bracket for tighten use original bolt and nut wit washer ID.3 and ID.4
7. Put fairing back to bike.
8. Insert bolt ID.2 and steel box ID.1 into the protectors and tighten it on the bracket.

Warning: We recommend use the glue of all threads. Medium strong.

(picture1)

