

CF119KD

Ducati Multistrada 1260S 2018-

Kit for Left Side			
ID	Description	Cat. No.	Pcs
1	Frame		1
2	Screw M10x30	882	1
3	Washer Flat M10	804	2
4	Dural. roller d=69mm	1313	1
5	Dural. roller d=7mm	1312	1
6	Rod M10x385x30x30		1
7	Self-lock nut M10	810	1
8	Screw M5x35	1056	1
9	Washer M5	1057	1
10	Plastic cover M10	X35	1
11	Screw M8x35	861	1

Kit for Right Side			
ID	Description	Cat. No.	Pcs.
1	Frame		1
2	Screw M10x30	882	1
3	Washer Flat M10	804	2
4	Dural. váleček d=61mm	1314	1
5	Dural. roller d=7mm	1312	1
6	RDmoto Sticker		2
7	Self-lock nut M10	810	1
8	Screw M5x35	1056	1
9	Washer M5	1057	1
10	Plastic cover M10	X35	1
11	Steel Strut	X119	1

We recommend using medium strenght thread glue during assembly.

Installation Instructions:

- 1.) On left side, take off original screws from the middle part of frame, as shown on photographs.
- 2.) In place of the original screw, push through the M10 ID.6 Rod and equip it with ID.4 roller, ID.1 frame, M10 ID.3 washer and M10 ID.7 nut. Do not tighten yet.
- 3.) In bottom part, dismount screw from the engine metal wedge and put M5 ID.9 washer onto the M5 ID.8 screw. Then push it through the bottom part of frame. Now Insert ID.5 roller between frame and the wedge and fix it there.
- 4.) Use the same procedure during installation of the right side. Remmember to connect both sides together in the bottom part with M8 ID.11 screw and in the upper part with steel strut ID.11, then attach it with M10 ID.2 screws and ID.3 washers.
- 5.) Finally, tighten all screws and nuts and put on the plastic covers for nuts. As a last step, you may put on RDmoto sticker.



Screw M10 ID.2 +
Washer M10 ID.3

Rod M10 ID.6 + Washer M10
ID.3+ dural. roller ID.4 + Nut M10
ID.7 + Cover M10 ID.10

Screw M8 ID.11

Screw M5 ID.8 +
Washer M5 ID.9

Dural. roller ID.4 + Washer
M10 ID.3+ Nut M10 ID.7 +
Cover M10 ID.10

Screw M10 ID.2 +
Washer M10 ID.3 +
Strut ID.11

Screw M5 ID.8 +
Washer M5 ID.9