

CF136

Moto Guzzi

V7 Griso/Norge/Breva 850-1200/Stelvio

FITTING KIT			
ID	Description	Cat. No.	Pcs
1	Crash frame	CF136	1
2	Bolt M10x40mm	854	2
3	Washer - flat M10	804	2

Instructions:

- 1.) Remove the original with the screws.
- 2.) Take screws ID.2 with washers ID.3.
- 3.) Insert the screws into the drop frame and mount it on the motorcycle.
- 4.) Tighten the screws to complete the installation.

Note - we recommend using a medium-strength (blue) safety glue on the threads of all screws.

