



CF33

Suzuki XF650 Freewind

Kit for the left side

No.	Description	Cat.no.	Pcs
1	Crash bar		1
2	Bolt M10x30mm	888	1
3	Pad M10 - spring	801	1
4	Dural. cylinder d=60mm	434	1
5	Steel adapter	X26	1
6	Advertising sticker RDmoto		1

Kit for the right side


No.	Description	Cat.no.	Pcs
1	Crash bar		1
2	Bolt M10x30mm	888	1
3	Pad M10 - spring	801	1
4	Dural. cylinder d=20mm	435	1
5	Bolt M8x110mm	844	1
6	Pad M8 - plane	802	2
7	Nut M8 - safety	809	1
8	Advertising sticker RDmoto		1

Installation:

Make the installation according to the instruction on the below attached photos. The installation of the left and right side is the same.

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

remove original duralumin cylinder and insert shorter duralumin cylinder d=60mm



steel adapter

bolt M10x30mm + pad M10 (spring)

bolt M10x30mm + pad M10 (spring)



remove original duralumin cylinder and insert shorter duralumin cylinder d=20mm

bolt M8x110mm to connect the left and right crash bar + pad M8 (plane) + nut M8 (safety)