

CF92

KTM 690 Enduro R 2012-

Kit for left side

Poz.	Popis	Kat.číslo	Počet
1	carsh frames upper	CF92	1
2	stirrup	X52	1
3	self-locking nut M6	948	2
4	washer M6 – plochá	947	2
5	bolt M10x45	848	1
6	Washer flat M10	804	2
7	dural. roller d=10mm	108	1
8	tape 3M		2
9	sticker RDmoto		1
10	dural. roller d=24mm	1248	1
11	bolt M8x20	823	1
12	washer flat M8	802	1
13	strut	X96	1
14	Self-locking nut M10	810	2
15	Dural. roller	DV433	1

Kit for right side

Poz.	Popis	Kat.číslo	Počet
1	carsh frames upper	CF92	1
2	stirrup	X52	1
3	self-locking nut M6	948	2
4	washer M6 – flat	947	2
5	bolt M10x45	848	1
6	washer flat M10	804	2
7	dural. roller d=10mm	108	1
8	tape 3M		2
9	sticker RDmoto		1
10	dural. roller d=24mm	1248	1
11	bolt M8x20	823	1
12	washer flat M8	802	1
13	bolt M10 x180	978	1
14	Self-locking nut M10	810	2
15	Dural. roller	DV433	1

Instruction :

Install the drop frames as instructed on the attached photos.

Mounting starts from the right side, so screws through, under the screw head is a washer and on the left side there are washers and nuts.

The installation of the frames for the left and right sides is the same.

We recommend using a medium-strength thread glue.

