



KTM11

KTM 790 Duke 2018-2019

KTM 890 Duke 2020-

Kit for the left side			
ID	Description	Cat.no.	Pcs
1	Steel adapter	732	1
2	Bolt M10x60mm	1048	2
3	Dural. roller l=8mm	1334	1
4	Dural. roller l=10mm	111	1
5	Washer M10	804	2
6	Dural. roller l=60mm	448	1
7	Bolt HEXA,M12x40mm	826	1
8	Washer M12 – flat	803	1
9	Dural. insert to the protect.	X2	1
10	Bolt M12x40mm	857	1

Kit for the right side			
ID	Description	Cat.no.	Pcs
1	Steel adapter	732	1
2	Bolt M10x60mm	1048	2
3	Dural. roller l=8mm	1334	1
4	Dural. roller l=10mm	111	1
5	Washer M10	804	2
6	Dural. roller l=60mm	448	1
7	Bolt HEXA,M12x40mm	826	1
8	Washer M12 – flat	803	1
9	Dural. insert to the protect.	X2	1
10	Bolt M12x40mm	857	1

Note – We recommend using medium strenght glue for threads of all screws (blue color).

Instructions :

- 1.) First mount the steel adapters on both sides (same screws + rollers L + P side) see photo.
- 2.) Then take a 60mm long dural. roller and mount it on the steel adapter with an M12x40mm screw (hex head) with an M12 washer.
- 3.) Now mount the protector itself with an M12x40mm screw (hex) with a dural. protector insert.
- 4.) The assembly of the left and right side is identical.

