

PM1

Engine protector

Fitting kit:

ID	Description	Cat.No	Qty
1	Crash slider	PM1	1
2	Bolt	817	3
3	AL cap	capPM	1

Assembly:

1. Dismantle original part.
2. Use original O-ring for slider.
3. Mount slider on engine.
4. Use bolts ID.2 and gripped AL cap.



Note: During installation, we recommend using glue on the threads (blue color). Do not use it on thread slider.