



PM3

Suzuki GSX 600, 1200 Bandit 1995-2005 Suzuki GSX 750, 1200 Inazuma 1996-2005

Kit for the left side:

ID	Description	Cat.no.	Pcs
1	Dural. adapter	716	1
2	Dural cylinder – 6mm	DV211	2
3	Bolt M14x24mm	980	2
4	Protector SL02		1
5	Bolt M10x20	819	1

Kit for the right side:

ID	Description	Cat.no.	Pcs
1	Dural. adapter	716	1
2	Dural. cylinder – 6mm	DV211	2
3	Bolt M14x24mm	980	2
4	Protector SL02		1
5	Bolt M10x20	819	1

Instructions:

1. Dismount original bolts from the frame of motorcycle.
2. Insert cylinders ID2 under dural. adapter ID1.
3. Mount dural. adapter and cylinders on the motorcycle using bolts ID3.
4. Mount protector on the adapter using bolt ID5.

We recommend to use safety glue on all threads (medium strong).

