

SPEEDO HEALER

Istruzioni di installazione cablaggio universale su :

Honda X-ADV 750 DCT

English:

Here is how to install the SH-U01 kit on the Honda Forza 750.

- Cut the Pink wire #11, about 4 cm away from the dash connector, then:
 - SH Green wire: connect to the Pink at the dash connector side
 - SH White wire: connect to the Pink at wiring harness side
- SH Red wire: tap the Pink wire, #2
- SH Black wire: tap the Green wire, #4

Do the SH function tests as per the manual, step #7:

http://www.healtech-electronics.com/docs/SHv4_U01_InstallGuide_en.pdf

Italiano:

Ecco come installare il cablaggio dello SH (Speedohealer) cod. SH-U01 su Honda Forza 750 :

- Tagliare il filo Rosa #11, circa 4 cm lontano dal connettore della strumentazione, quindi:
 - Collegare il filo **Verde** del cablaggio SH al filo Rosa che va al connettore della strumentazione.
 - Collegare il filo **Bianco** del cablaggio SH al filo Rosa/Verde che arriva dal cablaggio.
 - Filo **Rosso** del cablaggio SH: Collegarlo con morsetto ruba corrente al filo **Rosa** #2
 - Filo **Nero** del cablaggio SH: Collegarlo con morsetto ruba corrente al filo **Verde** #4
- Effettuare il test del funzionamento dello Speedohealer come descritto nel manuale.

