



## Italiano

- 1) Collegare il cablaggio dello SpeedoHealer (SH) al connettore 32 pin della strumentazione, o in alternativa al connettore 16 pin poco più lontano dalla strumentazione.
- 2) Tagliare il filo originale ROSA (riferimento allo schema sopra).
- 3) Collegare il filo BIANCO dello SH alla parte di filo Rosa originale lato cablaggio.
- 4) Collegare il filo VERDE dello SH alla parte di filo Rosa originale lato strumentazione.
- 5) Collegare il filo NERO dello SH al filo originale VERDE.
- 6) Collegare il filo ROSSO dello SH al filo originale NERO/ROSSO.
- 7) Effettuare le procedure come indicato sul manuale HT-SH-U01

## English :

- 1) Connect the SH wires either at the 32-pole dashboard connector or at the 12-pole Gray connector a bit farther from the dash:
- 2) Cut the Pink wire.
- 3) Connect the SH White to the Pink wire end at the wiring harness side.
- 4) Connect the SH Green to the Pink wire end at the speedometer side.
- 5) Connect the SH Black wire to the Green wire.
- 6) Connect the SH Red wire the Black/Red wire.
- 7) Perform the SH test procedure as per the SH-U01 install guide.