

SPEEDO HEALER

Istruzioni di installazione cablaggio universale su :

Integra e NC con cambio automatico DCT

Here's how to install the SH-U01 kit on the NC700:

- Cut the Pink/Green wire, about 5 cm away from the dash connector, then:
 - SH Green wire: connect to the Pink/Green at the dash connector side
 - SH White wire: connect to the Pink/Green at wiring harness side
- SH Red wire: tap the Pink/Blue wire
- SH Black wire: tap the Green/Red wire

Ecco come installare il cablaggio dello SH (Speedohealer) cod. SH-U01 sulle NC 700/750 :

- Tagliare il filo Rosa/Verde, circa 5 cm lontano dal connettore della strumentazione, quindi:
 - Filo **Verde** del cablaggio SH: Collegarlo al filo Rosa/Verde che va al connettore della strumentazione.
 - Filo **Bianco** del cablaggio SH: Collegarlo al filo Rosa/Verde che arriva dal cablaggio.
- Filo **Rosso** del cablaggio SH: Collegarlo con morsetto ruba corrente al filo **Rosa/Blu**
- Filo **Nero** del cablaggio SH: Collegarlo con morsetto ruba corrente al filo **Verde/Rosso**.